

SIEMENS

Gigaset 3015 Classic



Operating Instructions

and Safety Precautions 

General

Safety precautions

- Only use the **plug-type AC adapter supplied** as indicated on the underside of the unit.
- Never use ordinary (non-rechargeable) batteries. Only use **approved batteries** (rechargeable); otherwise the battery casing could be destroyed (dangerous), see the table on page 7.
- The mobile unit can affect medical equipment.
- The mobile unit can cause unpleasant humming in hearing aids.
- never set up the base station in bathrooms or showers.
- Never use the telephone in environments where there is a risk of explosion (e.g. paint shops).
- Batteries and telephones should always be disposed of in an environmentally responsible way.
- Always include the operating instructions when passing on your Gigaset unit to someone else.
- The battery compartments of the mobile unit contain the following information labels:



Observe correct polarity when inserting rechargeable batteries.



Use the battery type indicated in these operating instructions.

Displays

	Base station icon		Pause
	Charging status icon		Blank
	Mailbox function: New number in the caller list		Star key 
	Off hook		Hash key 
EXT	External connection		Recall key 
INT	Internal connection		Telephone PIN input
	Mobile unit locked		Keypad protection
	New message on telephone answering machine		

Gigaset 3000 Classic mobile unit: brief overview

Base station icon

- **Constant:** ready to receive
- **Flashing:** no base station contact

Speed dialling

Activate

Set key

- To save
- For settings

End call key

- End call
- **Handset on/off:** hold key down
- Cancel function

Recall key

- For systems and selected services
- **Pause:** hold key down!

Charging status

- ☺ full
- ☹ empty

Redial a number

Make internal call

Talk key

- Accept call
- Dial call number

Keypad protection


on/off, hold key down

Delete characters



Display keys

When icons are displayed above the 3 keys in the display, the meaning of these icons is as follows:



Keys on the base station



General

Quick reference guide

For information on mobile unit settings, see overview on the back of the operating instructions.

Function	Key combination
Activate/deactivate the mobile unit	Hold down  for 1 second
Activate/deactivate keypad protection	Hold down  for 1 second
Make an external call	 
Redial a number	 or  
Save a speed dial number	  e.g.     
Dial a speed dial number	  or e.g.  
Dial a number from call list	   
Set handset volume	    z. B.  
Mute microphone	 Microphone muted ;  Microphone on
Make an internal call	 e.g. 
Call all mobile units	 
Transfer call (connect)	 e.g.  
Internal enquiry call	 e.g.  ; terminate enquiry call: 
Set date	    set the date 
Set time	    set the time 
Play back messages	   or  key (base station)
Erase individual old messages	On base station:  during playback
Erase all old messages	On base station:   .

Contents

Index.....	62
General.....	2
Safety precautions	2
Displays	2
Gigaset 3000 Classic mobile unit: brief overview.	3
Keys on the base station	3
Quick reference guide	4
Preparing the telephone	4
Checking the contents of the package	4
Installing/connecting the base station	4
Inserting/charging the batteries	6
Attaching the belt clip.	8
Activating/deactivating the mobile unit.	8
Activating/deactivating keypad protection	8
Setting the date/time	9
Activating/deactivating the answering machine	10
Making calls	11
Making an external call	11
Making an internal call	11
Answering a call	12
Displaying the incoming call number (CLIP)	12
Muting the microphone	12
Picking up a call to the answering machine	13
Calling the mobile unit direct (DID).	13
Call pickup	14
Making a broadcast intercom call.	14
Fax calls	14
Paging a mobile unit	14
Enhanced telephone features	15
Redial	15
Speed dialling	15
Caller list/mailbox function	17
Open listening on the base unit	18
Recording an external call.	18

Contents

Cost-effective telephoning	19
Call-by-call support	19
Displaying the call duration	19
Displaying call charges	20
Call allowance account	21
Answering machine	23
Operation using the base station	23
Operating the answering machine with the mobile unit	28
Operating the answering machine when out of the office (remote operation)	33
Individual answering machine settings	34
Number of rings (charge save function)	34
Message length	34
Pause after message playback	35
Time stamp for each message	35
Monitoring on the base station	35
Broadcast intercom call (speaker call)	35
Recording quality	36
Individual mobile unit settings	37
Setting the ringer volume	37
Setting the ring tone	37
Setting the handset volume	37
Activating/deactivating beeps	37
Activating/deactivating base station display	38
Automatic talk	38
Resetting the handset to factory default	39
Registering at more than one base station	39
Changing the base station	39
Base station settings	40
Setting the ringer volume	40
Setting the ring tone	40
Setting the key beep	40
Activating/ deactivating music on hold	41
Setting pauses	41
Resetting the factory settings	42
Mobile unit security	43

Contents

Changing the telephone PIN.	43
Activating hot key (direct station selection)	43
Activating the telephone lock	45
Dialling an emergency number.	45
Deactivating the telephone lock	45
Base station security	46
Changing the base station's system PIN	46
Activating/deactivating the base station lock	46
Barring/enabling call numbers	47
Saving emergency numbers.	48
Operating more than one mobile unit	49
Registering additional mobile units.	49
Making an internal call	51
Forwarding a call	51
Internal enquiry call.	52
Accepting call waiting.	52
Collective call	52
Displaying the mobile unit number.	52
Monitor function on the mobile unit	53
De-registering mobile units	53
Disabling external dialling at individual mobile units.	54
Connecting a fax/modem	54
Activating/deactivating the ringer	55
Setting the ring delay/collective call/ direct inward dialling.	55
Connecting to a PABX system	57
Setting the dialling mode	57
Switching to tone dialling	57
Saving an external code (dial-out number)	58
Pause after external code.	58
Appendix	59
Maintenance	59
Troubleshooting	59
Guarantee/service/approval	60
Answering machine remote control	
Settings – Overview	back cover sheet

Preparing the telephone

Preparing the telephone

Checking the contents of the package

The package contains the following:

- one Gigaset 3015 base station
- one Gigaset 3000 Classic mobile unit
- one plug-type AC adapter
- one telephone cord
- one belt clip for the mobile unit
- two batteries
- one set of Gigaset 3015 Classic operating instructions

Installing/connecting the base station

Notes on installation



- The base station is designed for operation **in protected rooms** with a temperature range from +5°C to +45°C.
- Install the base station in a **central location** in the apartment/ house, e.g. in the hall.



- Do **not** operate the base station **in the bathroom**.
- Do not operate the mobile unit in environments where there is risk of explosion, such as a paint shop.

Range

The base station range is approx. 300 m outdoors and up to 50 m indoors. The base station icon indicates whether radio contact exists between the base station and mobile unit:



Base station icon is constant:

The mobile unit is ready for dialling and receiving calls.



Base station icon flashes:

No radio contact between the mobile unit and the base station – dialling or calling not possible!

Preparing the telephone


Connecting the base station



Use only the plug-type AC adapter supplied as indicated on the underside of the base station.

1.

- Insert **small jack on telephone cable** into  slot (clicks into place)
- Place cable in cables duct
- Insert telephone jack into telephone socket



2.

- Insert **small jack on mains cable** into  slot (clicks into place)
- Place cable in cables duct
- Insert AC adapter into mains socket

Preparing the telephone

Inserting/charging the batteries




- The **mobile unit** is already registered at the base station **when shipped**.
 - For information on registering **additional mobile units or replacement mobile units** (after repair), see page 49.
-

Inserting the batteries



- Never use ordinary (non-rechargeable) batteries. Only use **batteries that have been approved** (rechargeable), see table on page 7.
 - Only use approved batteries of the same type.
 - Never use non-Siemens charging units as these can damage the batteries.
-



- Insert the batteries, ensuring **correct polarity** – see figure on left.
- Insert the cover approx. **3 mm into the battery compartment** and push gently **forwards** until it clicks into place.
- **To open** the cover, press the grooved area on the cover and slide **back**.

Preparing the telephone

Charging the batteries

The batteries supplied are **not charged**.

To charge the batteries, insert the mobile unit in the base station or Gigaset 3000L charging unit (accessory) – you will hear the confirmation beep. The charging status icon flashes on the mobile unit display to indicate that a charging operation is in progress:

	Batteries empty		Batteries $\frac{2}{3}$ charged
	Batteries $\frac{1}{3}$ charged		Batteries full



- We recommend initially charging the batteries for at least 16 hours without interruption – irrespective of the charging status icon.
- Once the first charging operation is complete, you can replace the mobile unit in the base station after every call. Charging is controlled electronically. This ensures optimum charging and prolongs battery life.
- The batteries heat up during charging; this is normal and entails no risk.
- The battery charging status is only correctly displayed after uninterrupted charging/discharging. You should therefore avoid opening the battery compartment unnecessarily.

Approved batteries:

Nickel-cadmium (NiCd)	Nickel-metal-hydride (NiMH)
Sanyo N-3U (700 mAh)	Sanyo H-3 U (1500 mAh)
GP GP60AAKC (600 mAh)	GP GP130 AA HC (1300 mAh)
Varta 751RS (700 mAh)	GP GP150 AA HC (1500 mAh)
Mobile Power 700 (700 mAh)	Varta VH 1101 or Phone Power(1000 mAh)
Panasonic 60 DT (600 mAh)	Panasonic HHR-110 AA (1100 mAh)
	Friwo NiMH (1400 mAh)
	Toshiba TH-1200 AARE (1200 mAh)

Mobile unit operating times/charging times:


Capacity (mAh)	Stand-by time (hours)	Talk time (hours)	Charging time (hours)
700	up to 100	over 10	approx. 5
1100	up to 160	over 15	approx. 9
1500	up to 220	over 20	approx. 12

Power consumption:

- In standby mode (without charging) approx. 2W.
- In standby mode while charging approx. 5W.

Preparing the telephone

Attaching the belt clip



Press the belt clip onto the back of the mobile unit until the side protrusions click into place in the holes provided.

Activating/deactivating the mobile unit



Press the end call key for **1 second** – you will hear the confirmation beep*!



The mobile unit activates automatically as soon as you insert the batteries and place it in the base station/charging unit.

Activating/deactivating keypad protection

You can deactivate the mobile unit keys, e.g. when carrying the unit in your pocket or bag. This protects the keypad against inadvertent activation. Calls can be accepted with the talk key .



To activate/deactivate keypad protection, hold the key shown for **1 second** – you will hear the confirmation beep*!




Display when keypad protection is activated.

* 1 long tone = confirmation, 4 brief tones = error

Preparing the telephone

Press keys:




Setting the date/time

Setting the date

The date setting is required so that the entry date can be displayed in the caller list and output along with the answering machine messages.

Start the setting – the current setting is displayed; the current input point flashes:



e. g.

Enter **Day**.

If necessary press to skip backwards and re-enter.

e. g.

Enter **Month**.

e. g.

Enter **Year**.




Save the setting and quit the function.

Setting the time

The time setting is required so that the entry time can be displayed in the caller list and output along with the answering machine messages.

Start the setting – the current setting is displayed; the current input point flashes:



e. g.

Enter **Hours**.

If necessary press to skip backwards and re-enter.

e. g.

Enter **Minutes**.



Save the setting and quit the function.



The date and time must be reset after a power failure or after the base station AC adapter has been unplugged.

Preparing the telephone

Press keys:

Activating/deactivating the answering machine

The telephone answering machine can be used as soon as the base station has been connected.

Activation:

- ① Press the answering machine key on the base station.
The key lights up.

Deactivation:

- ① Press the answering machine key on the base station.
The key lamp goes out.

Press keys:

Making calls

Making an external call

External calls are calls using an external line.



Enter the call number.

If necessary, correct it with the delete key



Press the talk key to start the dial operation.



Ending a call:

Press the end call key.



- You can also **press the talk key** **first** and then enter the call number – each digit is dialled immediately.
- You can **cancel the dial operation** with the end call key .
- You can insert a **pause** with the recall key (hold key down).
- You can opt to **not save entries**, e.g. when controlling external telephone services: press the keys , all numbers entered afterwards are **not** saved for number redial.
- Adjust the mobile unit's handset volume (even during a call), see page 37.

Making an internal call

You can conduct **internal calls with up to 6 mobile units**.



Press the INT key – the mobile unit's internal call number is displayed.

e.g.



Enter the internal call number of the mobile unit you want to call.

Press: to call all mobile units



Ending a call:

Press the end call key.

Making calls

Press keys:



Answering a call

A call is signalled by the ringer.

Press the talk key.

or

if the auto talk feature is activated, remove the mobile unit from its base station (see status on delivery on page 39).




For information on setting the mobile unit's handset volume (even during a call), see page 37.

Displaying the incoming call number (CLIP)

If calling line identification presentation (CLIP) is supported by the network carrier, the caller's number and **EXT** appear on the handset's display:

e.g.



or

--- and **EXT** if the number was not received or

----- and **EXT** if the number has been suppressed by the caller.

or

the internal call number of another mobile unit and **INT**.

Muting the microphone

You can deactivate your microphone during external calls in order, for example, to talk privately to somebody in the room. The calling party cannot hear your conversation during this time.



Mute the microphone – the calling party on hold will hear music.



Re-activate the microphone.

Press keys:

Picking up a call to the answering machine

You can pick up a call to the answering machine while a message is being recorded.



Press the talk key.
Recording is ended and you can talk to the caller.

Calling the mobile unit direct (DID)

If you have set the DID function (see p. 55), then an external caller can dial the internal call number of a mobile unit after dialling your number.

After dialling your number, the external caller hears an advisory announcement, **irrespective of the telephone answering machine setting** (see p. 24).



Here is an example of a **typical advisory announcement** in association with direct inward dialling:

“Dial 1 for Mr. Miller, dial 2 for Ms. Mayer, dial 3 for the secretary’s office. If you do not have a specific contact, please dial *.”

If you have not recorded an advisory announcement, the caller will hear the standard advisory announcement “Please dial the extension you require, or hold.”

He then has 5 seconds to call the internal call number of a mobile unit.

If the required subscriber does not answer the call, after several rings the call is signalled on all mobile units as a hunt group call (for call tone delay settings see page 56).

If the call is not answered by a subscriber at this stage and if the telephone answering machine is switched on, after several rings (for setting see page 34), the call is answered with the set recorded announcement (announcement 1 or announcement 2). If the advisory announcement is set, the telephone answering machine will not answer the call.

Making calls

Press keys:



Call pickup

If a call is not answered at the mobile unit that has been dialled, you can also pick it up using another mobile unit.

Press the talk key.

Answer the call.

You are now connected to the external caller.



Making a broadcast intercom call

You can use the mobile unit to make a broadcast intercom call using the base station loudspeaker.

Call the telephone answering machine.

Switch on the broadcast intercom call function and speak.

End the broadcast intercom call function.

Press the End Call key.

Fax calls

You can register a Gigaset 1000 TAE cordless connector on the base station. This can be used to connect a corded telephone, a fax machine, or a modem (see p. 54). Fax calls are automatically forwarded to the fax machine by the base station.

Paging a mobile unit



Press the **key on the base station** – all mobile units ring.



To quit paging:

Press the key on the base station again or press the talk key  on a mobile unit.

Press keys:

Enhanced telephone features


Redial

Your mobile unit automatically stores the last five call numbers dialed. You can dial, change, display and delete these numbers.

Redialling a number



Display call numbers – the last number dialed is displayed:



Select a call number.



Press the talk key to start dialing.



- **Display keys** (see also p. 2)!
- **Modifying the call number displayed:**
 and supplement or press to correct.

Deleting all numbers

All **five redial numbers** are deleted.



1

TUV 8



Telephone PIN



Initiate the function.

Enter the mobile unit's telephone PIN and confirm (factory setting 0000).



2

Delete all numbers.



Confirm the delete action and terminate the function.

Speed dialling

The speed dialling list simplifies dialling for up to 10 call numbers.



- Numbers can also be saved **during** a call!
- **Display keys** (see also p. 2)!

Enhanced telephone features

Press keys:



Saving/changing/deleting call numbers

Press the set key and then the speed dial key – the entry for speed dial number 1 is displayed:

e. g. 

Blank or call number
Speed dial no. (memory location)

e. g.  oder 

Enter the speed dial number (digit **0** to **9**) or press  to scroll to the speed dial number you want to dial.



Confirm the selection.



Enter a new call number (destination) or change an existing call number. If necessary, delete the entire call number with .



Save the number – you will hear the confirmation beep.



Terminate the function.

Speed dialling



Press the speed dial key.

e. g. 

Enter the speed dialling number (digit **0** to **9**) or scroll with .



Dial the call number.



Changing a speed dial number before dialling:

Confirm the number displayed with , change the number and dial with .

Saving a call number from the redial list



Press the set key followed by the speed dial key.

e. g.  or 

Enter the speed dial number (digit **0** to **9**).



Confirm your selection.




Select a call number in the redial list.



Save the call number (confirmation beep) and terminate the function.


Deleting the speed dial list

All numbers are deleted!




Initiate the function.

Telephone PIN



Enter the mobile unit's telephone PIN and confirm (factory setting: 0000).



Confirm the delete action and terminate the function.

Enhanced telephone features

Press keys:


Caller list/mailbox function

If transferred, the call numbers for the **last 30 incoming calls** are stored in the caller list. **New entries** in the caller list are indicated by the  icon.


Dialling a number



Initiate the function – the following display appears briefly:



The following display then appears, alternating with the call number



Scroll down to the required entry.



Dial the call number – the entry is deleted from the caller list and stored in the redial list.


Caller list settings

You can make the following settings:

- only **unanswered calls** are saved (factory setting) **or**
- **all incoming calls** are saved



This operation **deletes all entries!**



Initiate the function.

e. g.

For example, **all calls** are to be saved.

Unanswered calls = **1**, all calls = **2**



Saving settings and terminate the function.

Enhanced telephone features

Press keys:



System PIN



Deleting the caller list

All entries are deleted!

Initiate the function.

Enter the base station's system PIN and confirm (factory setting: 0000).

Delete the caller list and terminate the function.

Open listening on the base unit

People in the room can be allowed to listen in on a call by means of the base station loudspeaker.

Activating/deactivating open listening

Activate/deactivate open listening.



Adjust the volume on the base station using the  and  keys. The new volume setting will be retained.

Recording an external call

You can record an external call on the telephone answering machine. This requires that the answering machine is switched on.

You are on a call.



Start recording.

The lamp in the telephone answering machine flashes and the call is recorded.



Terminate recording.

or



The external call and recording are terminated.

Press keys:

Cost-effective telephoning

Call-by-call support

This function simplifies the dialling operation when using a telephone company **other than** your regular telephone company.

● Using the speed dial key

- Save the call number of the telephone company as the speed dialling number "0", see "Speed dialling" page 15.
- **Hold down the speed dial key**  to display the telephone company's call number saved as speed dialling number "0".

Prerequisite: number is saved.



Hold down the speed dialling key – the telephone company's prefix code is displayed.



Enter the user's call number.



Press the talk key and dial the **complete number**.

● By "linking" the speed dial list

You can **save** prefix codes for various telephone companies **as speed dial numbers** and use them as follows when dialling:



e. g.



Display the prefix code you want to dial.

OK



Confirm the prefix code.



e. g.



Enter the user's call number from the speed dialling list **or** enter it manually.



Press the talk key and dial the **complete number**.

Displaying the call duration




The mobile unit automatically displays the current call duration if no counter pulses are transmitted.

Cost-effective telephoning

Press keys:

Displaying call charges

Requirement: You have requested transmission of counting pulses from your telephone company and the correct price per unit is set. Display begins after the first counter pulse is received.

e. g. 

Setting the price per unit

You must set the price per unit to ensure that the correct call charges are displayed.

If you set the **price per unit to zero, units** are displayed instead of call charges.



- Every modification sets the counters back to zero. The amounts in the call allowance accounts are retained.
- If the price per unit is set to zero, then the amounts in the call allowance accounts are also erased.

   
System PIN 

Initiate the function.

Enter and confirm the system PIN of the base station (factory setting: 0000) – the current setting is displayed.

If necessary use the  key to switch between display with decimal places (00.00) and without decimal places (0).

e. g.  

Enter the price per unit.

If necessary use the  key to set the charge factor to “00.0”. This is the setting for displaying only units.

Save the setting (confirmation beep) and terminate the function.

Displaying/deleting charges

You can display the charges **per mobile unit** as well as charges for **all mobile units**. If units are set, then, of course, whole units will be displayed.

   
System PIN 

Initiate the function.

Enter and confirm the system PIN (factory setting: 0000) – the numbers of all registered mobile units are displayed (flashing).

Cost-effective telephoning

Press keys:



● Total charges for all mobile units:

Press key.

If necessary, clear the display with and confirm this with .



Terminate the function.

or

● Charges for a particular mobile unit:

e. g. Enter the number of the mobile unit – the following is displayed:

e.g.

0000020 00001

Charges for last call
Total charges for all calls

If necessary, clear the display with and confirm with .

To check other mobile units: 2x .



Terminate the function.

Displaying last call charge

If this function is activated, the total cost of last call is always displayed after the talk key is pressed .



System PIN

Initiate the function.

Enter and confirm the system PIN (factory setting: 0000).

e. g.

e.g. activate display.
On =1; Off =0



Save the setting and terminate the function.

Call allowance account

Requirement: Call charges are displayed.


You can set up a call allowance account for **all** mobile units. This function allows you to allocate a credit allowance for **outgoing external calls** to a mobile unit. Current credit is displayed during the call.

The following functions are available on mobile units with active call allowance accounts:

- Answering incoming calls
- Making internal calls
- Dialling the emergency numbers stored in the base station

Cost-effective telephoning

Press keys:



System PIN

e. g.

e. g.



System PIN

e. g.

e. g.



When credit has expired or is exhausted:

A warning beep is emitted during calls when the last five units have been reached. The line is disconnected when credit is exhausted.



If the base station is set to **call units**, then the call allowance account is also recorded with units, see page 20.

Defining/displaying credit

Initiate the function.

Enter and confirm the system PIN of the base station (factory setting: 0000) – the numbers of all registered mobile units are displayed (flashing).

Enter the call number of the mobile unit - the **current account status** for the mobile unit is displayed.

Enter the credit amount, e.g. 20.00
(up to 999.99 or 99999; depending on the price per unit).
The amount can be set to zero using the delete key (←).

Save credit, terminate function and then **activate the call allowance account** as described below.

Activating/deactivating the call allowance account

Initiate the function.

Enter and confirm the system PIN (factory setting: 0000) – the numbers of the mobile units are displayed.

Enter the call number of the mobile unit - the current setting is displayed: 30 = the function number and mobile unit number initially entered and setting 1 **or** 2.

e.g. activate call allowance account.
On = **1**; Off = **2**

Save the setting and terminate the function.

Press keys:

Answering machine

The answering machine is ready for use after the base station has been started.

The answering machine provides support during operation with appropriate messages on the mobile unit display and voice announcements.



The answering machine can be operated directly using the base station keys or with a registered mobile unit or external telephone.



The keys on the base station correspond to the relevant digits on the mobile unit (see p. 28).



Operation using the base station

Your answering machine is ready for use as soon as the base station has been started. The date and time must be set if messages are to be announcement with time details. The answering machine will use a standard message read by a female voice until you record your own announcement:

"There is no one available at present to answer your call, Please leave a message after the tone."

Activation:



Activate the answering machine.

The answering machine key lights up on the base station. The answering machine is ready to receive messages.



If memory is full and an advisory announcement has been recorded, then the answering machine automatically switches to "Advisory announcement without recording option."

Deactivation:



Deactivate the answering machine.

The lamp goes out.

Answering machine

Press keys:

Selecting announcements

On delivery, the answering machine already has a standard announcement that cannot be erased:

"There is no one available at present to answer your call, Please leave a message after the tone."

This announcement will be used if you have not recorded your own announcement or if you have erased your personal announcement.

You can choose between the following announcements:

- **Announcement 1** with message recording and final announcement
- **Announcement 2** with message recording and final announcement
- **Advisory announcement** without recording option
The advisory announcement is also required for the direct inward dialling function (see p. 13).



Initiate announcement selection.



Jump to the previous announcement.



Jump to the next announcement.



The selected announcement is active.

The announcement setting is stored even after the answering machine has been deactivated.



If you select **advisory announcement** without recording option, the answering machine cannot be switched on or switches itself off automatically.

Recording announcements

Before you record an announcement, you must first select the one you require (see above). You can record announcements with or without a final announcement that runs after the caller has left a message.

Recording an announcement without final announcement



Initiate recording.



The answering machine automatically calls all registered mobile units. recording is started from the mobile unit that answers the call.



Press the talk key on the mobile unit.

You will hear the ready tone. The answering machine key on the answering machine flashes.

You can now record your announcement or advisory announcement.

A **typical announcement** is as follows:

"You have reached Mr. Smith's office. I am not available at the moment, but you can leave me a message. Please speak after the tone."

Answering machine

Press keys:

A **typical advisory announcement** is as follows:

"Our office is closed at present. We are open from Monday to Friday between 9 a.m. and 5 p.m."

Appropriate announcements for direct inward dialling are outlined on page 13.

Recording stops automatically:

- if the maximum recording time of 170 seconds is exceeded
- if the speaker pauses for more than 2 seconds,



Press the End call key on the mobile unit.

The recorded text is played back.

Recording an announcement with final announcement



Press to initiate recording on the base station.



When this key is pressed on the base station, the answering machine automatically calls all registered mobile units. Recording is started by the mobile unit that answers the call.



Press the talk key on the mobile unit and record your announcement.



When this key is pressed on the base station, you will be prompted to record a final announcement.

A **typical final announcement** is as follows:

"The maximum time allowed for your message has been reached. Thank you for calling."



Press this key on the base station to terminate recording.

The recorded messages are played back.

Checking announcements



Press this key on the base unit to initiate playback.



Press this key on the base unit to play back the currently set announcement.



You can adjust the volume of playback (via the base station loudspeaker) using the \ominus and \oplus keys on the base station. The volume setting is stored.

Erasing announcements



Press this key on the base unit to initiate the function.



Press this key on the base unit to erase the announcement currently set.



When you erase an advisory announcement, the answering machine automatically switches off. The permanent standard announcement is activated when you have erased an announcement.

Answering machine

Press keys:

Playing back messages

The answering machine key on the base station flashes and the  symbol appears on the mobile unit display if new messages have been recorded.



Listen to messages.

Playback begins with the first new message. Old messages are played back after the last new message.

The following options are available while playing back messages:



Decrease or increase volume.



Stop playback (pause).



Continue playback.



Jump to the start of the current message.



Jump to the previous message (press several times).



Jump to the next message.



Jump to later messages (press several times).



Mark the current message as "new" (not yet played).



Terminate playback.




If the time is not set (see page 9), then date and time are not indicated.

Marking the current (old) message as "new"



Play message.



or



Jump to the required message (press one or more times).



The message is marked as "new."

Answering machine

Press keys:

Erasing messages

You can erase old messages on a universal or individual basis.

Erase all old messages



Press when the answering machine is in standby mode.



Press within 6 seconds.
All messages are erased.




You can cancel the instruction to erase by pressing the  key after the message "Confirm erase with Return key".

Erase individual old messages



Message playback begins.



or



Jump to the required message (press one or more times).



Press during playback.
The individual message is erased.

Recording information

You can use the mobile unit to record information for other users.



Initiate recording

The answering machine automatically calls all mobile units. Recording is started from the mobile unit that answers the call.



Press the talk key on the mobile unit. You will hear the ready tone.

Record your message.



Recording will automatically cease if you pause for longer than 8 seconds during your message.



Press this key on the base unit to terminate recording.
You will hear the End tone.

Answering machine


Press keys:



Operating the answering machine with the mobile unit

You can operate the answering machine using your mobile unit or when out of the office (see p. 33).

The digits on the mobile unit or on an external telephone correspond to the following keys on the base station:



Activate/ deactivate answering machine



WKVZ
9

Set up a connection to the answering machine.

TKV
8

Activate or deactivate.



Terminate connection.

Press keys:

-   Set up connection to answering machine.
-  Check current announcement.
-  Jump to next announcement.
-  Jump to previous announcement.
-  Set new announcement.
-  Terminate connection.

Recording an announcement

-   Set up connection to answering machine.
-   Start recording of required announcement.
-  Record final announcement when prompted.
-  Terminate recording.
-  Terminate connection.

 If you **do not** wish to record a **final announcement**, press the  key **twice in short succession**.

Checking an announcement

-   Set up connection to answering machine.
-   Play back selected announcement.
-  Terminate connection.

Erasing an announcement

-   Set up connection to answering machine.
-   Erase selected announcement.
-  Terminate connection.

Answering machine

Press keys:

Playing messages

The answering machine key on the base station flashes and the  symbol appears on the mobile unit display if new messages have been recorded. Pressing the keys listed below enables the following steps to be executed.

You can play back messages using the digit keys of the mobile unit or by means of the display keys.

Using the digit keys to play messages

-   Set up connection to answering machine.
-  Play all messages.
-  Stop playback (Pause).
-  Continue playback.
-  Jump to the start of the current message.
-   Jump to the previous message (press several times).
-  Jump to the next message.
-   Jump to the next message (press several times).
-  Mark current message as "new" (not yet played).
-   Terminate playback.
-  Terminate connection.

Playing messages using the display keys

-   Display messages.
- The number of new and old message appears on the display.
-  The first new message is played.
- The caller's number, if transmitted, and the date/time of the call alternate on the display.
- The following options are available:
-   Jump to previous message.
-   Jump to next message.

----08 07----

  OK

08912345678

  OK

 You can press  to dial the call number immediately or  to erase the display.

-  Terminate playback.


Press keys:



Set up connection to answering machine.



Play back messages.



Jump to the required message (press one or more times).



The message is marked as "new".



Terminate connection.

Erasing messages

You can erase old messages on a universal or individual basis.

Erasing all old messages



Set up connection to answering machine.



Initiate erasing.



Press within 6 seconds.

All old messages are erased.



Terminate connection.


Erasing individual old messages



Set up connection to answering machine.



Play back messages.



Jump to the required message (press one or more times).



Press during playback.

The message is erased.



Terminate connection.

Recording information



Set up connection to answering machine.



Initiate recording.

Record your message after the ready tone.



Terminate recording.



Terminate connection.

Answering machine

Press keys:



Making a broadcast intercom call

You can use the base station loudspeaker to make a broadcast intercom call. The answering machine should not be recording a message at the time the broadcast intercom call is made.

Set up connection to answering machine.

Activate the broadcast intercom call function.

Terminate the broadcast intercom call function.

Terminate connection.

Press keys:

Operating the answering machine when out of the office (remote operation)

You can operate the answering machine of your base station from any other telephone (e.g. in a hotel or phone box) in the same way as from your mobile unit using the digit keys.

However, you must first change your system PIN, see page 46.


You will find details of the functions and corresponding steps starting on page 28.

 Your external telephone must have touch tone dialling. Otherwise you must use a tone transmitter.



Dial your own call number.

You will hear your announcement.




Press the  key and enter the system PIN.

Activating the answering machine from remote station

If you forgotten to switch on your answering machine. Let your telephone ring for about one minute.

You will hear the message "Please enter PIN."



Press the  key and enter the system PIN.

Your answering machine is now active.

 The appendix includes remote control instructions in handy cheque-card format.

Helps and status enquiries

You can request help and status information from an external telephone.



Check the device status and the remote control functions.

The following status messages are heard in succession:

- Number of messages
- Advisory announcement/ no advisory announcement exists
- Announcement set
- Answering machine on/ off
- Remaining memory time
- No time setting exists, where applicable
- Function assignment for keys 0...9 and *.



Skip status messages.



Terminate help and status enquiry.

Individual answering machine settings

Press keys:

Individual answering machine settings

The factory settings for the answering machine are designed to offer you maximum benefits. Changes to the settings can be made from the mobile unit.

Number of rings (charge save function)

Initiate setting.


You can choose between 2 and 9 rings or select charge save function 0. When the charge save function is active, you can hear if new messages have been received.

The answering machine is activated after

- 2 rings: new messages have been received
- 4 rings: no new messages have been received.

Factory setting: charge save function (0).

Save setting and terminate function.



Message length

Initiate setting.

Factory setting: 120 seconds.


30 seconds.

60 seconds.

120 seconds.

Unlimited.

Save setting and terminate function.



Individual answering machine settings

Press keys:



Pause after message playback

Initiate setting.

Switch on this function (1); this causes the answering machine to pause after each message is played back.

Factory setting: no pause (0)



Save setting and terminate function.



Time stamp for each message

Initiate setting.

You can switch off the time stamp (0).

Factory setting: Message with time stamp (1).



Save setting and terminate function.



Monitoring on the base station

Initiate setting.

If you do not wish to monitor a message during recording (0).

Factory setting: monitoring on (1).



Save setting and terminate function.



Broadcast intercom call (speaker call)

Initiate setting.

If the answering machine is controlled remotely by means of a mobile unit or an external telephone, then the person making the call can use the base station loudspeaker to make a broadcast intercom call that is not recorded. If the call is an external call, it can be answered using any mobile unit during the broadcast intercom call. You can deactivate this function (0).

Factory setting: Speaker call allowed (1).



Save setting and terminate function.

Individual answering machine settings

Press keys:



Recording quality

Initiate setting.

The available recording time depends on the recording quality. You can choose between a long recording time (2), high quality (3) and automatic mode (1).

In automatic mode the answering machine automatically switches from high quality to long recording time when memory is low. All previously received messages are compressed.

Factory setting: Automatic (1).

Save setting and terminate function.



The answering machine cannot be used during compression and calls cannot be recorded. An error signal is heard when any base station key is pressed (except the paging key).

Press keys:

Individual mobile unit settings

Setting the ringer volume

You can choose between **5 ringer volumes** (ringing) and the **“crescendo” ring** (increasing volume).

JKL
5

e. g.

GHI
4OK
→→

Initiate the function - you will hear the current ringer.

Enter the number of the required ringer volume.
Volume levels = **1 to 5**; crescendo = **6**

Save the setting.

Setting the ring tone

You can choose between **10 ring tones**.

MNO
6

e. g.

DEF
3OK
→→

Initiate the function – you will hear the current ring tone.

Enter the desired ring tone (**0 to 9**).

Save the setting.

Setting the handset volume

You can set the **handset volume** (volume of conversation) to any of **3 levels** – even during a call.



1

0

OK
→→

e. g.

ABC
2OK
→→

①

Initiate the function.

Enter the required handset volume (**1, 2 or 3**).

Save the setting.

Terminate the function (**do not press** this key during a call).


Activating/deactivating beeps

You can activate/deactivate the following warning and signal tones:

- **Confirmation beeps:** confirmation beep (1 tone) when you complete inputs/settings; error beep (4 short tones) when you make an incorrect entry.
- **Key beep:** every keystroke is confirmed.
- **Battery warning beep:** the battery requires recharging.

Individual mobile unit settings

Press keys:




Activating/deactivating confirmation beeps

Initiate the setting.

For example, deactivate confirmation beeps.
Deactivate = **0**; activate = **1**

Save the setting and terminate the function.




Activating/deactivating key beep

Initiate the setting – the current setting is displayed.

For example, deactivate the key beep.
Deactivate = **0**; activate = **1**

Save the setting and terminate the function.



Activate/deactivate the battery warning beep

The battery warning beep is generated when the charging status of the battery in the mobile unit falls below a predefined level.


Initiate the setting.

For example, deactivate the battery warning beep.
Deactivate = **0**; activate = **1**;
battery warning beep only during a call = **2**

Save the setting and terminate the function.

Activating/deactivating base station display

If the display is activated, the currently valid base station is displayed when the mobile unit is idle, e.g. -1-.




Initiate the setting.

For example, activate the display.
Activate = **1**; deactivate = **0**

Save the setting and terminate the function.

Automatic talk

When this function is active, you can answer a call by removing the mobile unit from the base station/charging unit.



Initiate the setting.

For example, deactivate auto talk.
Deactivate = **0**; activate = **1**

Save the setting and terminate the function.

Individual mobile unit settings

Press keys:



Resetting the handset to factory default

This setting does **not** alter the **telephone PIN**.
Base station registrations are maintained.

Mobile unit factory settings:

Speed dial numbers, redial, hot key	deleted
Handset volume, ringer tone	1
Ringer volume	5
Automatic talk, key beep, battery warning beep, confirmation beep	on
Base station display	off

Initiate the setting.

Enter the telephone PIN and confirm (factory setting 0000).

Reset settings to factory default and terminate the function.

Registering at more than one base station

You can operate your mobile unit at up to **4 base stations**.

 For information on registration at **Gigaset 3015** see page 49

Changing the base station

Prerequisite: the mobile unit is registered at several base stations.

You can choose one of the following:

- Set the mobile unit to **select automatically** the best base (factory setting).
- Set the mobile unit to **priority base station** – the mobile unit searches for other base stations if this is not found within 30 seconds.
- Set the mobile unit to **a fixed base station**.

Press the set key followed by the INT key.


For example, set Base 1 as the priority base.

For **automatic selection:** enter (0).

For **priority base:** enter the base number **twice**.

For **fixed base:** enter the base number **once**.

Save the setting and terminate the function.



Base station settings

Press keys:

Base station settings

All base station settings are made **via the mobile unit**.

Setting the ringer volume

You can choose between **5 ringer volumes**, the **“Crescendo” ring** (increasing volume) and **ringer off**.



Initiate the setting – you will hear the current ringer and the current setting is displayed.

e. g.

Enter the number of the required ringer volume.

Volume levels = **1 to 5**;

Crescendo = **6**;

Ringer off = **0**



Save the setting and terminate the function.

Setting the ring tone

You can choose between **10 different ring tones**.



Initiate the setting – you will hear the ring tone and the current setting is displayed.

e. g.

Enter the required ring tone (**0 to 9**).



Save the setting and terminate the function.

Setting the key beep



Initiate the setting – the current setting is displayed.

System PIN

Enter and confirm the base station system PIN (factory setting: 0000).

e. g.

For example deactivate key beep.

Deactivate = **0**; activate = **1**



Save the setting and terminate the function.

Press keys:



e. g. 0



Activating/ deactivating music on hold

This refers to the music that the caller hears when placed on hold, e.g. during an internal enquiry call.

Initiate the setting.

Enter and confirm the base station system PIN (factory setting: 0000).

For example, activate music on hold.
Deactivate = **0**; activate = **1**

Save the setting and terminate the function.

Setting pauses

Pause after picking up an outside line

You can use this function to set the length of the pause that is automatically inserted after you have pressed the talk key  and before the call number is transmitted.



e. g. 2



Initiate the function.

Enter and confirm the base station system PIN (factory setting: 0000).

Enter the pause length.
1 second = **1**; 3 seconds = **2**; 7 length = **3**; 2.5 length = **4**

Confirm the setting and terminate the function.

Pause after the recall key

You can use this function to set the length of the pause that is inserted with the recall key .



e. g. 1



Initiate the function.

Enter and confirm the base station system PIN (factory setting: 0000).

Enter the pause length.
0.8 seconds = **1**; 1.6 seconds = **2**; 3.2 seconds = **3**

Save the setting and terminate the function.

Base station settings

Press keys:

Resetting the factory settings

When resetting the base station, the **system PIN is not changed** and mobile unit registration is not affected. You can:

- reset **all** factory settings, see table below
- delete the **caller list** only
- delete **costs/units** information only

Base station factory settings:

Ringer volume	5
Ring tone	1
Price per unit	00.00
Disable/enable call numbers, system lock, last call costs	Off
Number for disabling/enabling, credit accounts, stored emergency numbers	Deleted
External dialling (all mobile units)	Possible
Dialling mode	DTMF, flash (250 ms) DTMF, adjustable flash
Flash time (on telephone systems)	80 ms 100 ms
Pause after reset key	800 ms
Pause after dial out on outside line / external code	3 s



System PIN

0



Initiate setting.

Enter and confirm the base station system PIN (factory setting: 0000).

For example, reset setting to the factory default. Reset to factory default = **0**; delete caller list = **1**; delete costs/units = **2**

Confirm the delete action and terminate the function.

Press keys:



Mobile unit security

You can change the telephone PIN, configure direct station selection or lock your telephone (mobile unit).

Changing the telephone PIN

Important functions/settings are protected by the mobile unit's telephone PIN (**P**ersonal **I**dentification **N**umber).

 **Do not forget your PIN!** The PIN can only be reset by calling the **Siemens hotline**, see page 60.



Initiate the function – the following appears:



Information on PIN input
Function code previously entered

Telephone PIN 

Enter the current telephone PIN and confirm (factory setting: 0000).

2x new PIN

Enter the new telephone PIN twice (4 digits, a dash is deleted every time a digit is entered).



Confirm the new telephone PIN – you will hear the confirmation beep, the new PIN is saved.




Terminate the function.

Activating hot key (direct station selection)

When direct station selection is activated, **every key pressed** activates a call to the **stored** direct call number. This enables someone to send a call for help.

The following sequence of operations enables you to store, change or completely delete direct call numbers.



Initiate the function.

Telephone PIN 

Enter and confirm the telephone PIN (factory setting: 0000).



Press keys.



Enter the direct call number.

If necessary, correct or delete the number by pressing .
Remember to use the external code on telephone systems!

Mobile unit security

Press keys:



Save the number – you will hear the confirmation beep, the **direct station selection has been activated**, the direct call number appears on the display, as well as the **☎-0** symbol.

Press keys:



- If no **direct call number** is saved (display Ξ), then the telephone lock is activated after \rightarrow is pressed – the \rightarrow symbol appears.
- To **deactivate the direct call number/ telephone lock** see below.

Activating the telephone lock

All functions with the exception of emergency call are unavailable when the telephone (mobile unit) is locked. You can still be reached, however. Simply press the talk key  to accept a call.



Initiate the function.

Enter the telephone PIN and confirm (factory setting: 0000).



Activate the telephone lock.

Save the setting – you hear the confirmation beep, \rightarrow appears on the display.

Dialling an emergency number

Prerequisite: you have saved the emergency number in the base station, (see page 48), and the mobile unit is locked.



Press the talk key.



Enter the emergency number, e.g.112, 999.

Deactivating the telephone lock



- If **hot key is active**, you must **complete the following operations quickly** to avoid dialling the direct call number!



Initiate the function.

Enter the telephone PIN and confirm (factory setting: 0000).



Deactivate the telephone lock.

Save the setting and terminate the function.

Base station security

Press keys:



Base station security

Changing the base station's system PIN



System PIN

2x new PIN



Initiate the function.

Enter the current system PIN and confirm (factory setting: 0000).

Enter the new system PIN (4 digits) twice.

Confirm the new base station PIN – when you hear the confirmation beep, the new PIN has been saved.

Terminate the function.

Activating/deactivating the base station lock

Outgoing external calls are blocked **for all mobile units** when the base is locked.

Stored **emergency numbers** can still be dialled.



System PIN

e. g. 



Initiate the function.

Enter the system PIN and confirm (factory setting: 0000).

For example, activate the base lock.
Activate = **2**; deactivate = **0**

Save the setting and terminate the function.

Press keys:

Barring/enabling call numbers

You can use this function to **bar specific call numbers**, e.g. all international numbers (00...). You can also specifically **enable these numbers**. Barring/enabling actions affect **all mobile units**.

All external numbers dialled are checked. Dialling is cancelled and the barred digits are displayed if the number called matches a **barred number**. This does not happen if the **number is enabled**.


Saving/changing/deleting call numbers

You can save 5 numbers. The numbers can be displayed, changed, and deleted at any time.



Initiate the function.

Enter the system PIN and confirm (factory setting: 0000) – the first entry is displayed:



If necessary, press to scroll to the entry required (memory location).



Select the entry displayed.



Enter the call number, e.g. **00** to bar **international calls**, or change. If necessary, press to delete the number



Save the entry and terminate the function **and now activate barring/enabling** as described below.

Activating/deactivating call barring/enabling



Initiate the function.

Enter the system PIN and confirm (factory setting: 0000).

e. g.

e. g. bar numbers.

Bar numbers = **1**;

Enable numbers = **3**;

Deactivate call barring/enabling = **0**



Save the setting and terminate the function.

Base station security

Press keys:



Saving emergency numbers

The emergency number (999, 112 or 9112) has already been saved. You can save an additional **4 emergency numbers**. The emergency numbers are valid for **all mobile units**.




An **emergency number can be dialed**, even if the telephone is locked or a credit account has run out.

Saving/changing/deleting emergency numbers

Initiate the function.

Enter the system PIN and confirm (factory setting: 0000) – the first entry is displayed:



If necessary, press to scroll to the required entry (memory location).



Select the entry displayed.




Enter or change the emergency number (up to 16 digits). If necessary, press to delete the number



Save the entry and terminate the function.

Operating more than one mobile unit

Press keys:



Operating more than one mobile unit

Registering additional mobile units



- You can register and operate up to **6 mobile units** at your 3015 base station.
- Every Gigaset 3000 Classic mobile unit can be registered at up to **4 base stations**.

Registering a Gigaset 3000 Classic mobile unit



The **mobile unit** is already registered at the base station when **shipped**.



e. g. ^{OK}

Initiate registration – the base station numbers are displayed.

Enter the **number of the base station** and confirm with ^{OK} .
Base station 1=**1**; base station 2=**2**;
Base station 3=**3**; base station 4=**4**



Normally, enter **1** for base station 1 when registering for the first time. When registering the mobile unit at additional base stations, e.g. at work, enter **2**, **3** or **4** as the number of the base station.

System PIN ^{OK}

Enter the base station's system PIN and confirm (factory settings: 0000) – the base icon is flashing.

At base station

Press the base station key until a signal tone is generated at the base station (hold key down for approx. 10 seconds) – unassigned internal call numbers are displayed after a few seconds, e.g. 23456 (number 1 is assigned to the mobile unit supplied).

e. g. ^{ABC}

Enter the **internal call number of the other mobile unit** – the base icon is displayed **continuously** (stops flashing) **if registration is successful**.

Your mobile unit is ready for operation!

Operating more than one mobile unit

Press keys:



↓ Base settings OK



↓ Register OK

System PIN OK

At base station

e. g.

Registering a Gigaset 3000 Comfort mobile unit

Step 1:

Press the menu key.

Select a function.

Select the base station.



Normally, enter **1** for base station 1 when registering for the first time. When registering the mobile unit at additional base stations, e.g. at work, enter **2, 3** or **4** as the number of the base station.

Call the additional menu.

Select the function.

Enter the system PIN and confirm (factory setting: 0000) – e.g. **Registration Procedure Station 1** is displayed.

Step 2:

Press the base station key until a signal tone is generated at the base station (hold key down for approx. 10 seconds) – unassigned internal call numbers are displayed after a few seconds, e.g. 23456 (number 1 is assigned to the mobile unit supplied).

Step 3:

Enter the **internal call number of the other mobile unit** – the base icon is displayed **continuously** (stops flashing) **if registration is successful**.

Your mobile unit is ready for operation!

Operating more than one mobile unit

Press keys:

At base station



● Registering Gigaset 1000/2000

For information on preparing these mobile units, see the relevant operating instructions.

● Registering third-party mobile units

Prerequisite: the non-Siemens mobile unit complies with the **GAP standard!**

GAP (Generic Access Profile) is a European standard for the interaction of cordless telephones and base stations.

Refer to the operating instructions of the mobile unit to be registered for information on how to register it at a **GAP base station**.

Preparing your base station for registration:

Press the base station key **until a signal tone** is generated at the base station (hold down for approx. 10 seconds).

Your Siemens base station assigns the **first unassigned** internal call number to the mobile unit after registration.

Making an internal call

Internal calls are conducted with your other registered mobile units – **free of charge**



Press the INT key – the relevant internal call number is displayed.

e. g.



Enter the internal call number of the mobile unit you want to call.

To call all mobile units press: 



Ending a call:

Press the end call key.

Forwarding a call

You can forward an external call to another mobile unit (transfer).



Press the INT key – the external user hears music on hold.

e. g.



Dial the internal call number of the mobile unit.



When the user answers:

Press the end call key to transfer the call.

Operating more than one mobile unit

Press keys:



e. g.



or



Internal enquiry call

You are on a call with an external user. You can call another internal user for an internal call without clearing down the initial connection. You are automatically reconnected to the external user when you end the internal call.

The external user (call) is placed on hold and can hear music on hold.

Dial the internal number of the mobile unit you want to call.

To call all mobile units press:

End the enquiry call to revert to the caller placed on hold.

Accepting call waiting

The call waiting tone (1 brief tone) is generated when you receive an external call while conducting an internal call; **EXT** flashes on the display.

Press the end call key – the **internal call is cleared down**. Wait for the external call (auto talk).

Answer the external call when the mobile unit rings.

Press the recall key – the **internal call is cleared down** and you are immediately connected to the external caller.

Collective call

All mobile units are called and ring. You can accept the call at any mobile unit by pressing the talk key .

The busy tone is generated if no one is available to answer the call.

Displaying the mobile unit number

Press the INT key – the mobile unit's internal call number is displayed.

Ending the display:
Press the end call key.

Operating more than one mobile unit

Press keys:


 e. g. 

   
System-PIN 

e. g. 

Monitor function on the mobile unit

Prerequisite: at least 2 mobile units are registered.

You can use this function to listen in on an external call at another mobile unit.

You are conducting a call with an external user:

The call is placed on hold.

Enter the call number of the other mobile unit – the other mobile unit rings, the other internal user presses the talk key .

You are reconnected to the external user. The other internal user can hear the conversation.

Deactivating monitoring:

The external connection is not affected, the internal user hears the busy tone.



The internal user can terminate monitoring by replacing the handset.

De-registering mobile units

A mobile unit that has been de-registered from a base station (e.g. to protect against unauthorized use) cannot be used to make calls at this base station.

Initiate de-registration.

Enter the system PIN and confirm (factory setting: 0000) – the numbers of all registered mobile units are displayed.

Enter the internal call number of the mobile unit **to be de-registered** (number is no longer displayed).

Confirm de-registration.

Operating more than one mobile unit

Press keys:

Disabling external dialling at individual mobile units

The factory setting permits you to make external calls from each registered mobile unit. You can use the disabling function to **prevent external numbers from being dialled by individual mobile units**.

You can use "blocked" mobile units to:

- make internal calls
- accept external calls
- dial the emergency numbers saved at the base station (see page 45).



System-PIN

e. g. 2

e. g. 0



Initiate the setting.

Enter the system PIN and confirm (factory setting: 0000) – the numbers of all registered mobile units are displayed.

Enter the internal call number of the **mobile unit to be disabled**.

For example, deactivate external dialling (block).
Deactivate = **0**; activate = **2**

Save the setting and terminate the function.

Connecting a fax/modem

You can register fax machines, modems and corded telephones at the base station in the same way as a mobile unit via a cordless **Gigaset 1000 TAE** connector. To do this, you must modify the **device type for the Gigaset 1000 TAE** as described below:



System-PIN

e. g. 4

e. g. 1



Initiate the function.

Enter the system PIN and confirm (factory setting: 0000) – all registered mobile units are displayed.

Enter the internal call number of the TAE.

Set the device type.
"corded " telephone/mobile unit = **1** (factory setting); fax = **2**;
modem = **3**

Save the setting and terminate the function.

Operating more than one mobile unit

Press keys:



e. g. DEF 3



Activating/deactivating the ringer

All mobile units ring immediately to signal an incoming external call – collective call (factory setting). The calls can be accepted at all mobile units by pressing the talk key . However, you can **deactivate** the ring on **individual mobile units** – these mobile units no longer ring when external calls are received.

Initiate the setting.

Enter the system PIN and confirm (factory setting: 0000) – all mobile units **"with" ringer** are displayed.

Enter the internal call numbers of the mobile unit:

- call number is **displayed** = ringer **on**,
- call number is **not displayed** = ringer **off**.

Save the setting and terminate the function.

Setting the ring delay/collective call/direct inward dialling

This function allows you to switch from collective call (factory setting) to ring delay or direct inward dialling:

- If **collective call** is activated, **all mobile units ring immediately** when external calls are received.
- If **ring delay** is activated, calls are signalled first at the **priority mobile unit** and then at the other mobile units, for example, after 4 rings. The priority mobile unit and the ring delay (number of rings) must first be defined.
- If **direct inward dialling** is activated, an external caller can call a specific mobile unit directly (see p. 13).



1

or

ABC 2

or

DEF 3



Initiate the setting.

Enter the system PIN and confirm (factory setting: 0000).

Set collective call.

Set the ring delay.

Set direct inward dialling.

Save the setting and terminate the function.

Operating more than one mobile unit

Press keys:



System PIN

e. g. ABC 2



System PIN

e. g. JKL 5



Setting a priority mobile unit

The mobile unit with 1 as call number is automatically the priority mobile unit – and rings first (factory setting).

You can set any **other mobile unit** as the **priority mobile unit** as described below:

Initiate the function.

Enter the system PIN and confirm (factory setting: 0000) – the priority number is displayed.

Enter the call number of the **priority mobile unit**.

Save the setting and terminate the function.

Setting ring delay

You can set the **number of rings** allowed before a call rings on the **other mobile units**.

Initiate the function.

Enter the system PIN and confirm (factory setting: 0000) – the current setting is displayed, e.g. 3.

Enter the number of rings.

The call rings on the other phones after: 2 rings = 2 to 9 rings = 9

Save the setting and terminate the function.

Press keys:

Connecting to a PABX system

Setting the dialling mode

Only necessary if your telephone system does **not** operate with **DTMF** (dual-tone multifrequency signalling), and flash – see the operating instructions for your PABX system.

Options:

- DTMF, Flash 250 ms
- DTMF, adjustable flash time
- DP (dial pulsing)

Setting the dialling mode:

Initiate the function.

Enter the system PIN and confirm (factory setting: 0000).

Set the dialling mode.

DTMF, flash 250 ms = **1**; DTMF, adjustable flash time = **2**; DP = **4**

Save the setting and terminate the function.



Setting the flash time

Prerequisite: you have switched to DTMF, adjustable flash time as described but your telephone system requires a different flash time.

Initiate the function.

Enter the system PIN and confirm (factory setting: 0000).

Set the flash time.

80 ms = **1**, 100 ms = **2**, 120 ms = **3**, 180 ms = **4**,
250 ms = **5**, 300 ms = **6**, 600 ms = **7**

Save the setting and terminate the function.



Switching to tone dialling

If you are operating the base station in a telephone system with dial pulsing (DP), you can switch to tone dialling (DTMF), for example to check an answering machine.

Prerequisite: a connection is active!

Press the save key.

Activate tone dialling – tone dialling is active until the call is cleared down.



Connecting to a PABX system

Press keys:

Saving an external code (dial-out number)

Prerequisite: A dial-out number, such as "0" must be dialled before the actual telephone number on all external calls.

The external code is also known as a **prefix code or system code (SC)**.



- Please note that the external code must be entered when saving **emergency numbers, call numbers for the speed dialling list** and **network provider prefix numbers**.
- Since an **emergency call cannot** be made with the fixed emergency numbers, e.g. 999, you should **re-save** the emergency numbers with the external code, **e.g. 0999** for security reasons.
- The **external code** that you save "here", is always automatically inserted before the call numbers in the caller list and dialled.



System PIN

e. g. 0



Initiate the function.

Enter the system PIN and confirm (factory setting: 0000).

Enter the external code (up to 3 digits) or change.

Save the setting and terminate the function.

Pause after external code

Prerequisite: you have saved an external code and would like to change the default pause.

The pause set here is always inserted by the base station after the external code. For information on whether and how long this pause must be, see the operating instructions for your PABX system.



System PIN

e. g. 1



Initiate the setting.

Enter the system PIN and confirm (factory setting: 0000).

Enter the pause length.

1 second = **1**; 2 seconds = **2**; 3 seconds = **3**; 6 seconds = **4**

Save the setting and terminate the function.

Appendix

Appendix

Maintenance

- Simply wipe the base station and mobile unit with a **damp cloth** or an anti-static wipe. **Never** use a **dry cloth** as this can cause static discharge.

Troubleshooting



Resetting the mobile unit factory settings, see page 39.
Resetting the base station factory settings, see page 42.

Fault	Possible cause	Solution
No display	Mobile unit not activated	Hold down the end call key  for 1 second
	Batteries flat	Charge the batteries.
No reaction to key-stroke	Keypad protection activated	Hold down the  key for 1 second
No radio connection to the base station –  flashing!	Mobile unit outside the base station range	Move closer to the base station
	Mobile unit not registered	Register the mobile unit (page 49)
	Base station not activated	Check the jacks on the base station (page 4)
Mobile unit does not ring	Ringer off	Activate the ringer (page 37)
Base station does not ring	Ringer off	Activate the ringer (page 40)
External call numbers cannot be dialled	Base lock activated	Deactivate lock (page 46)
	Handset lock activated	Deactivate lock (page 45)
	Call number matches a barring code	Barring codes (page 47)
	Credit on call allowance account exhausted	Call allowance account (page 21)
	External dialling disabled	Enable external calling (page 54)

Appendix

Fault	Possible cause	Solution
Units/ costs not displayed	No count pulse	Apply for transmission of count pulse from telephone company
Call charges are not displayed	Unit price = 0	Set the unit price (page 20)
The called party cannot hear	(INT) was pressed – the microphone is muted	Press (R) to activate the microphone
The caller's number is not displayed	Caller has withheld number	--
The answering machine reports that the PIN is invalid during remote operation	The system PIN entered is invalid or the PIN is set to 0000.	Re-enter the PIN or set a system PIN that is not 0000.
The answering machine does not record messages, announcements or information.	Memory is full	Erase old messages. Play back new messages then erase them.
The answering machine is on but does not record messages and cannot be monitored.	The answering machine is currently compressing messages	Wait 3 to 5 minutes. The answering machine will then be fully functional again.
On telephone systems: No connection or incorrect connection	No dial-out code or the wrong dial-out code has been entered.	Enter the correct dial-out code/ check the code (page 58)

Guarantee/service/approval

Guarantee

Siemens offers a six-month guarantee for this device from the date of purchase from the dealer. Over this period, Siemens will rectify all material or manufacturing defects by repairing or replacing the defective terminal.

The guarantee shall not cover damage caused by improper use, wear and tear or third party access. The guarantee shall not cover consumables or defects which only slightly decrease the value or serviceability of the device.

Service

Service contact:

- **Great Britain:** Siemens hotline 0345 908070



Siemens Service should only be contacted if problems arise with the unit. Your specialist dealer will be happy to answer any questions on unit operation. Contact your network provider for questions concerning telephone connections.

Approval

Gigaset 3015 has received approval for operation in your country, as indicated on the underside of the base station.

In the case of approval in compliance with I-CT R37 (from gazette):

"This equipment has been approved to [Council Decision 99/303/EC - "CTR 21"] for pan-European single terminal connection to the Public Switched telephone Network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN termination point. In the event of problems, you should contact your equipment supplier in the first instance."

Index

Display keys, Cover
Displays, Cover
Mobile unit brief overview, Cover
Safety precautions, Cover

A

Activating
 beeps 37
Activating/ deactivating the mobile unit 8
Activating/deactivating key beeps 38
Activating/deactivating the answering machine
 23
Activating/deactivating the base lock 46
Activating/deactivating the ringer 55
Activation
 Battery warning beep 38
 Confirmation beep 38
 Key beeps 38
 Keypad protection 8
 Mobile unit 8
 Music on hold 41
 Telephone lock/direct station selection 45
Advisory announcements 24
Announcements (AM)
 Erasing 25
 Recording 24
 Selection 24
Approval 61
Automatic talk 38

B

Barring/enabling call numbers 47
Base station
 Activating/deactivating music on hold 41
 installing 4
 Reset to factory settings 41
 Setting pauses 41
 Setting the date 9
 Setting the ring tone 40
 Setting the time 9
 Switching 39
Battery warning beep 37
Beeps
 battery warning beep 37
 confirmation beeps 37
 key beep 37
Belt clip 8
Broadcast intercom calls
 Setting 35

C

Call allowance account 21
Call pick-up 13
Call pickup 14
Call recording 18
Call waiting 52
Call-by-call 19
Change PIN
 Base station PIN 46
Changing settings (AM) 34
Changing the PIN
 Mobile unit PIN 43
Charge save function 34
CLIP (displaying incoming calls) 12
Collective 52
Collective call 52
Confirmation beeps 37
Connecting a modem/fax 54
Connecting the base station 5
Contents of package 4

D

Deactivating
 beeps 37
Deactivation
 Battery warning beep 38
 Confirmation beep 38
 Key beeps 38
 Keypad protection 8
 Mobile unit 8
 Music on hold 41
 Telephone lock/direct station selection 45
Direct Inward Dialling 13
Direct station selection (hot key) 43
Displaying call charges 20
Displaying charges 20
Displaying the call duration 19
Displaying/deleting total charges 20
Displaying/erasing charges 20
DP (Dial Pulsing) 57
DTMF (dual-tone multifrequency signalling) 57

E

Emergency call number
 Dialling 45
 Save 48
Enquiry calls (internal) 52
Error beep 37

F

- Faults (Help) 59
- Fax calls 14
- Fax/modem connection 54
- Flash time 57
- Forwarding/transferring a call 51

G

- GAP standard 51
- Guarantee 60

H

- Help with faults 59
- Hot key (direct station selection) 43

I

- Inserting and loading the batteries 6

K

- Keypad protection 8

M

- Mailbox function 17
- Making a broadcast intercom call 14
- Making a call
 - Internal 51
- Making an external call 11
- Making calls
 - Answering a call 12
 - External 11
 - Internal 11
- Making internal calls 11
- Messages (AM)
 - Deleting 27
 - Playing back 26
 - Terminating playback 26
- Mobile unit settings (overview) 59
- Mobile unit
 - Activating/deactivating base station display 38
 - De-registration 53
 - Disabling external dialing 54
 - Displaying internal numbers 52
 - Registering additional mobile units 49
 - Registering at more than one base station 39
 - Reset to factory setting 39
 - Switching to another base station 39
- Mobile unit lock
 - Activating 45

- Deactivating 45
- Monitor function
 - On the mobile unit 53
- Monitoring 35
- Muting the microphone 12

O

- Open listening
 - On the base station 18

P

- Paging (a mobile unit) 14
- Picking up a call to the answering machine 13
- Preparing the mobile unit 6

Q

- Quick reference guide, Cover

R

- Range 4
- Recording a call 18
- Recording information (AM) 27
- Redial 15
- Remote control (AM) 67
- Remote enquiry (AM)
 - Activating the answering machine 28
 - Playing messages 30
 - Playing/ selecting announcements 29
 - Recording announcements 29
 - Using help 33

S

- Save
 - Call allowance 22
 - Credit 22
 - Emergency call number 45
 - System PIN 46
 - Telephone PIN 43
- Saving
 - Speed dial number 16
- Service 60
- Setting collective call/ ring delay/direct inward dialing 55
- Setting ringer volume 37
- Setting the date 9
- Setting the handset volume 37
- Setting the price per unit 20
- Setting the ring tone 37
- Setting the time 9

Settings

- Base station music on hold 40
- Date 9
- Handset volume 37
- Pauses 41
- Ring tone on base station 40
- Ring tone on mobile unit 37
- Ringer volume on base station 40
- Ringer volume on mobile unit 37
- Settings – Overview, Cover
- Speaker call 35
- Speed dialing 15

T

- Telephone lock 45
- Telephone systems
 - Flash time 57
 - Save pause after external code 58
 - Saving external code 57
 - Set the dialing mode 57
 - Switch to tone dialing 57
- Terminating message playback (AM) 26
- Tone ringer 55
- Transferring a call 51
- Troubleshooting 59

Answering machine remote control

The keys for the remote operation of the answering machine have the same functions on all telephones, mobile units and tone transmitters. The "cheque card" shows how the control commands and keys correspond and how to initiate a remote enquiry using an external telephone.

	3		6		9		#
				Speaker call			Status/Help
	2		5		8		0
	1	4		7		*	
				New			

Initial operation

 Dial your own number. You will hear your announcement.

 +  Press the hash key and enter the answering machine PIN.
Control the answering machine using the digit keys.


Switching on the answering machine:
Let the telephone ring for about 1 minute.

 +  Press the hash key and enter the answering machine PIN.
The answering machine switches on.




Settings – Overview


Mobile unit settings



Answering machine settings



Base station settings



Issued by
Information and Communication Products Group
Hofmannstraße 51, D-81359 Munich

© Siemens AG 1999. All rights reserved.
Subject to availability.
Right of modification reserved.

Siemens Aktiengesellschaft

Reference no.: A31008-G3015-B001-1-19
Printed in Germany.
09/99

Internet: <http://www.siemens.com/gigaset>